



Pro Wash/Dry

Multistage Automated Washing System
Designed and Engineered for Dental Professionals



Fast

Mechanical jetting
washes your parts in
just 10 minutes.

Easy

Simple touchscreen
controls deliver a superior
wash experience.

Clean

Automatic pumps make
sure you never have to
touch alcohol.

Automated 2-Stage Wash & Dry

Mechanical Jetting **PATENTED**

Using a high-speed motor that spins at over 10,000 RPM, Mechanical Jetting is a patented system that rapidly delivers agitated alcohol to 3D printed parts with only 500mL of solvent.

10-minute Wash Cycle

Thanks to the efficiencies gained through Mechanical Jetting, SprintRay Pro Wash/Dry can complete a full, two-stage wash cycle in just ten minutes.

Set it and Forget it

Place the SprintRay build platform or included wash basket in the wash cradle and press 'Start.' Pro Wash/Dry automatically performs a two-stage wash and dry.



Easy Solvent Management

Science Removes the Guesswork

Precalibrated hydrometers sink in clean IPA and float when it's dirty. Since you always know when it's time to replace IPA, your parts will always come out clean.

Efficiency to Write Home About

Pro Wash/Dry can operate with a half-liter of alcohol and recycle from one chamber to another with a single touch.

Quick-connect IPA Draining

Snap the hose into place, creating a water-tight seal to drain IPA in a way that is clean, efficient, and safe.